

A10/10D

10.1 Inch android with DVD player

User Manual

Thank you for purchasing our products,
and pls read this manual before operating the product.

●Precautions:

- 1.Please don't expose the unit in humid,dusty,steam/lampblack/sunlight or other related severe environment.
- 2.Please use gentle cloth to clean the unit, and don't use diluent or any other chemical cleaner.
- 3.Put the unit away from places overhot or overcool, storage temperature: -25°C~ 75°C and operating temperature: -15°C~ 65°C .
- 4.Please don't drop or strike the unit.
- 5.Please don't try to repair the unit by yourself, because the unit contains precision electronic component, unprofessional detachment or repairment may damage the unit. If any problem, pls turn off the power , stop using the unit, and notify your local retailer.

● Configuration Information:

Operation system: Android 6.0

Processor: ARMA7 Quad 1.3Ghz

GPU : Mali 400 Mp2

RAM/ROM : 1G DDR 16G

Extended storage: 128G

Screen size: 10.1 inch IPS(16:9)

Resolution ratio: 1280×RGB×800

Contrast ratio: 400

Luminance: 400cd /cm²

Touch screen: G+G capacitive multi-touch screen

Battery: li-Polymer Battery 3.7V/4500mAh (Optional)

● Main Functions

WIFI: 2.4G 802.11 b/g/n

Smart link: Miracast / Airplay

DVD type: Slot-in DVD

Disc format: DVD,DVD+RW,DVD-RW,DVD+R, DVD-R ,CD-RW, CD-R,CD...

Audio format: AAC, AC3, ARM, APE, DTS, MP2, MP3, OGG, WAV, WMA...

Video format: DVD,DVD+RW ,DVD-RW,DVD+R ,DVD-R ,CD-RW, CD-R,CD,ASF, AVI, DAT, FLV, M2TS, MKV, MOV, MP4, MPG, RM, RMVB, TP, TS, VOB, WMV...

Picture format: BMP, GIF, JPG, PNG...

Built-in functions: Bluetooth, Microphone, FM Transmitter, G-Sensor

External connector: USB, HDMI output, TF card slot, Earphone jack, Restoration jack.

Power adapter: DC 12V, 1A

● Basic Operation

1、 Power on

Pressing the power button for 2 seconds, the cold boot would be 30 seconds.


2、 Power off

Pressing the power button for 2 seconds, shutdown menu can be seen, then clicking the “off”key.


3、 Screen saver

Press the power button to enter the screensaver.



4、 Return to the previous interface

Press button “”, then the screen return to the previous manipulation.


5、 Return to homepage

Pressing button “” can bring the unit to homepage.


6、 Adjust volume

“” , “” respectively signify the decrease and the increase of the volume. Pressing them you will find the volume menu and the volume ratio. And the menu will disappear by itself after 3 seconds without any manipulation.

7、 Find programs in the background

Press “”, you can find all the programs which you operated recently, clicking anyone of them as you want. Sliding the screen left or right, can turn off this function.

- Homepage



User can click Disc, Smart-link, Video , Music, Picture , Internet , Application or Setting to use their corresponding functions.

◀ The detailed picture is as following:

- Main function introduction

- 1. DVD player(A10D only)


Clicking the image of Disc, or the Disc App can open the DVD player interface, then place the disc in the slot at right direction, and the unit will suck in the disc by itself and playing the files.



- 2. Video player

Clicking "Video" can open the video app. The unit can play the video files directly stored in the unit or in the external storage device.

◀ The detailed picture is as following:



3. Music player

Clicking "Music" can open the music app. The unit can play the music files stored in the unit or in the external storage device.


◀ The detailed picture is as following:



4. Other applications

Clicking "Application" can open the application page. You can find all the apps installed in the unit, and click anyone as you want.

◀ The detailed picture is as following:




5. Internet

Clicking the "Internet" on the homepage can open the browser.

◀ The detailed picture is as following:

6.Smart link


This function supports Android system and Airplay system, and by this function, user can share all resources in their phone with the unit.



7.Picture browsing

Inserting USB or TF card, clicking the "Picture" , user can find the picture list, and browse the pictures through opening the document folder and then clicking open the picture files inside.


◀ The detailed picture is as following:



8.Setting

Clicking open the setting menu, user can adjust the properties of functions like Wi-Fi, Network, Display, Language and language input, Data usage and so on.


◀ The detailed picture is as following:



Special suggestion:

restoring factory setting will bring this unit to its original situation, and under this situation, your personal information will not be kept anymore.

- FM transmitter




FM transmitter can transmit the audio to the radio in the car .User can hear the audio by radio when the frequency is the same as the unit.

◀ The detailed picture is as following:

- HDMI output

User can perform the HDMI Output function by connecting the unit with external display device, clicking "Display-HDMI Setup" in settings, then inserting the cable of HDMI into corresponding jack.


- Startup logo setting



Within the option of "About Device", clicking "Change Booting Logo", and inputing password "000000". User can choose the LOGO image among the given pictures.

◀ The detailed picture is as following:


- File manager



Clicking the image of file manager, user can find the file manager interface. This function is used for checking the using condition of the unit's storage and the SD card's storage, and manage the files.

◀ The detailed picture is as following:

- Smart link






Connection with iphone

1. Open the iphone settings, open the cellular mobile data and personal hotspot
2. Open the device WiFi and connect the hotspot , In the "Smart link" feature select "iphone WiFi", and open the iphone airplay function, select the device ID, when the device shows the following interface , it has been successfully connected.

◀ The detailed picture is as following:




Note: Download the app can even achieve two-way mutual control operation. (please scan the two-dimensional code on the device)

- Product schematic




The front

SCREEN



The side



The back


DISC SLOT-IN/OUT (A10D only)

BRACKET SWITCH

HEAT EMISSION HOLE

BRACKET

• Installation guide



1. Lifting the car's headrest, choosing right plastic rings according to the iron pole's diameter, and clamping the iron pole with the plastic rings (ensuring the flat inward), fixed the plastic rings with U-hardware preliminarily.

◀ The detailed picture is as following:



2. Placing the bracket box between the iron poles (with the switch upward), pushing the U-hardware into the bracket box, then place the box in the middle .

◀ The detailed picture is as following:



3. Insert the back bracket of the unit into the bracket box, push the switch into the locking place, and adjust the bracket to a perfect place. If user want to detach the unit from the bracket, pls open the locking first, otherwise compulsively pulling out the unit will damage its structure.

◀ The detailed picture is as following:

Finally, thanks again for purchasing our products. If any interest, pls directly contact us, and we will do our best for serving you.