

LBS TRACKING TERMINAL WARRANTY CARD

Please Note:

Any upgrade of this products later on , notifications will only be sent to distributors;
Any changes on appearance or colour, pictures are only for information, take practicality as standard;

The warranty card only suits the following IMEI terminal;

Please keep the warranty card safe, also show the warranty card and original purchase receipt before repair services;

Specific warranty range as follow;

This warranty card is a basic access to repair service, please fill out the table carefully and keep it safe.

LBS Global Tracker

Insert a SIM Card (GSM card with GPRS service), then you can login the live tracking platform www.gps588.com (English version available) by account *the last 10 digits of IMEI* and password *123456* directly.

Call the terminal SIM card number, rings 2 times then hang up the phone, the terminal will reply the terminal current geography location SMS. By sending *6660000* to terminal, it will reply the terminal current geography location SMS. By sending *8880000* to terminal, it will reply the Google map website hyperlink, you can check the location by using yours mobile browser.

8

PERSONAL ANTI-THEFT/MONITORING

LBS+SMS/GPRS

Fast Installation Instruction & User Manual



9

In order to install and operate the LBS tracker in right method and properly, please read this Fast Installation Instruction & User Manual before installation, Thank you.

A.Package & Accessories

Charger*1; User Manual *1;

B.Functions

Real-time monitoring, history replay.

SMS & web-portal location enquiry.

Support up to 9 SOS emergency phone call numbers.

10

C.Technical Parameter

GMS frequency: 900/1800MHz or 850/1900MHz;

Standby: 7 days;

Dimension: 44.0(L)*37.0(W)*12.0(H)mm;

Net weight: 26g;

D.Terminal Operations

1.Insert the SIM card, after LED flashes 3 times, the devices starts.

2.Phone Number Bind Setting

Send SMS: #711# Contact Number#Password#No.##

11

And reply Config OK or Password ER.

e.g. #711#123456789#0000#1##

#711#987654321#0000#2##

Up to 9 numbers can be set in the contact list.

No.from 1 to 9.

3.SMS get Location

Send SMS: 6660000, to get the current address location information;

Send SMS: 8880000, to get the current address location Google map link;

12

4.Voice Monitoring

Use the emergency contact phone number to call the device, it will enter the voice monitoring status.

5.SOS Alarm

Press the SOS 3 seconds, it will call the emergency contact automatically.

6.Call Back Function

Send SMS: 01 to open the Auto-Call-Back function

13

Send SMS: 02 to close the Auto-Call-Back function

When the sound around the device exceeds 60 decibels, the device will call the bound phone number automatically.

7.Power Saving Mode

Send the following commands to device, and it will reply Config ok to confirm the configuration successful. Initial password is 0000

Super Power Saving Mode: #730#37#1#0000## , Standby 8 days.

Mediate Power Saving Mode: #730#32#1#0000## , Standby 5 days.

14

Normal Power Saving Mode: #730#30#1#0000## , Standby 3 days.

8.Change Password

Send SMS: #770#new password(4 digits)#old password(4 digits)##

After it succeed, it will reply Config Ok, otherwire, Password ER.

e.g. #770#1111#0000## Password changed from 0000 to 1111.

E.Live Tracking Monitoring Platform

15

Web Address: www.gps588.com

If you already have a login account and password information, you can login our platform directly, or please contact your distributor and ask them to open you an account and provide you the password.

Input the address link in your computer browser, input the account and password, then login to your service platform.

About the use method of platform, please ask your distributor for Service Platform User Manual.

16