

无线键盘使用说明书

(for Windows)




包装包含:说明书×1 蓝牙键盘×1 USB充电线×1

- 1 -

产品型号规格

- 1.蓝牙标准接口
- 2.有效操作距离: 10米内
- 3.调制方式: GFSK
- 4.工作电流: < 8mA(触摸板工作时)
- 5.待机电流: < 0.3mA
- 6.睡眠电流: < 40uA
- 7.充电电流: 100mA/200mA(背光款)
- 8.待机时间: > 100天
- 9.充电时长: 2-3小时
- 10.工作时长: ≥ 30/100小时(关闭背光)
- 11.锂电池寿命: 3年
- 12.按键力度: 80±10g
- 13.按键寿命: 500万次点击
- 14.工作温度: -10°C - +55°C

入门指南



- 2 -

蓝牙键盘连接操作步骤

- 1.拨动开关至ON处开机,按 **FN + 蓝牙图标** 进入配对搜索,蓝牙灯进入闪烁模式
- 2.打开并解锁平板,点击“设置”图标



- 5.点击找到 蓝牙 键盘: Bluetooth Keyboard, 连接成功后蓝牙指示灯长亮
- 6.关闭连接页面后就可以正常使用



⚠ 蓝牙设备名称以实际为准

- 3 -

蓝牙快捷功能说明

静音	音量减	音量加
播放/暂停	上一曲	下一曲
搜索	共享	无线
设置	Fn 辅助功能	触摸开关
背光开关	颜色变换	蓝牙配对
全选	输入法切换	截屏

- ⚠ 注: 以上为功能参照表, 具体以实际为准
- 注: 背光版本的键盘才有此按键
- 🌈 颜色调节: 直接单击, 共7种颜色循环
- 💡 亮度调节: Fn组合按键, 共3档亮度循环

触控板功能操作说明

一、鼠标功能实现

触控板功能	鼠标功能	手指操作示意图	手指动作
移动	移动光标		滑动手指
单指快速点击	鼠标左键		单指敲击
双指点击	鼠标右键		双指敲击
单指快速双击	左键双击		单指快速双击
单指快速双击不松拖动	左键选中目标拖动		单指快速双击不松拖动
双指垂直移动	中键垂直滚动		双指垂直移动
双指水平移动	中键水平滚动		双指水平移动

- 4 -

二、快捷功能实现

手 势	手指操作示意图	功能说明
放 大		放大目标, 类似于按住 Ctrl 键滚动鼠标滚轮
缩 小		缩小目标, 类似于按住 Ctrl 键滚动鼠标滚轮
三指点击		Win+S组合键 (打开Cortana)
四指点击		Win+A组合键 (打开Action+Center)
三指左滑		Alt+Shift+Tab组合键 (活动窗口切换)
三指右滑		Alt+Tab组合键 (活动窗口切换)
三指上滑		Win+Tab组合键 (打开任务浏览窗口)
三指下滑		Win+D组合键 (显示桌面)
从左边缘向右滑		Win+Tab组合键 (打开任务浏览窗口)
从右边缘向左滑		Win+A组合键 (打开Action+Center)
从上边缘向下滑		Win+I 组合键 (缩小打开的窗口)
从下边缘向上滑		Win+B组合键 (显示隐藏任务栏)

- 5 -

① 注意

- 1.在长期不使用时, 我们建议关闭键盘, 以延长电池的寿命
- 2.为了获得更长的电池使用寿命, 建议电源灯闪烁时才给键盘充电, 每次充电时间最好不少于2小时

节能休眠模式

当键盘15分钟无操作指令将会进入休眠模式, 工作指示灯将会熄灭, 需要使用时, 只需要按任意键并等待5秒左右, 键盘将会唤醒, 工作指示灯将长亮

故障清理

- 1.确定已开启电源
- 2.确定键盘在可操作的距离范围内
- 3.确定电池有电量
- 4.确定平板电脑的蓝牙设置已打开
- 5.确定无线键盘和蓝牙连接
- 6.确定无线键盘与蓝牙已配对

按下电源开关不工作后, 先给键盘充电, 然后重置再开机

清洁

用清水, 酒精或类似酒精的消毒剂清洁键盘

充电

当电池电量低时, 低电量指示灯会不断闪烁, 这时需给键盘充电

- 1.将原装附件USB线Type C 端连接到键盘上的充电接口
- 2.将USB线A端连接到电源适配器或电脑USB接口(电源适配器不包括)
- 3.键盘充电过程中, 充电指示灯会长亮, 充满后亮绿灯

- 6 -

保修卡

用户填写资料

公司或个人全称 _____

通讯地址 _____

电话 _____ 邮编 _____

所购产品名称及型号 _____

购买日期 _____

本有限质保不涵盖由于以下原因导致的问题或损坏:
(1) 意外事件、误用、操作不当或任何未经授权的维修、改装或者拆卸
(2) 操作或维护不当, 使用过程中违反产品说明或连接不适当的电源
(3) 或者使用并非本公司提供的消耗品(如备用电池), 但适用法律禁止此类限制的情况除外



- 7 -

Wireless Keyboard User Manual

(for Windows)




Package included: Instruction manual×1 Wireless keyboard×1 USB charging cable×1

- 1 -

Product Specifications

- 1.Bluetooth Interface Standard
- 2.Operating Distance Available: 10 meters
- 3.Modulation System: GFSK
- 4.Working Current: < 8mA (When the touchpad is working)
- 5.Standby Current: < 0.3mA
- 6.Sleeping Current: < 40uA
- 7.Charging Current: 100mA/200mA (Backlight)
- 8.Standby Time: > 100 days
- 9.Charging Time: 2-3hours
- 10.Working Time: ≥ 30/100 hours (turn off the backlight)
- 11.Lithium Battery Life: 3 years
- 12.Key Strength: 80 ± 10g
- 13.Key Life: 5 Million Stroke
- 14.Operating Temperature: -10°C - +55°C

Getting Started Guide



- 2 -

Bluetooth Keyboard Connection Procedure

- 1.Toggle the switch to ON to start, press **FN + 蓝牙图标** to enter the pairing search, then the bluetooth indicator enter flashing model
- 2.Open and unlock your device and click on the "Settings" icon



- 5.Click the device: Bluetooth Keyboard, bluetooth indicator is on for a long time after successful connection
- 6.It can be used normally after closing the connecting page



⚠ Bluetooth device name shall be subject to the actual situation

- 3 -

Keyboard Shortcut Function Description

静音	Volume -	Volume +
Play/Pause	Previous track	Next Track
Search	Sharing	Wireless
Set Up	Function Key	Touch Pad Switch
Backlight Switch	Colors Conversion	Bluetooth pairing
Select all	Input method switch	Screen capture

- ⚠ Note:The above is the function reference table,and the details shall be subject to the actual situation
- Note: 此键只有背光版本的键盘才有
- 🌈 Color adjustment: direct click,a total of 7 color cycles
- 💡 Brightness adjustment: Fn combination button,a total of 3 brightness cycle

Touchpad Operation Instruction

一、Touchpad Operation Function Description

Touchpad Function	Mouse Function	Finger Schematic	Finger Movement
Move	Move the cursor		Swipe your finger
Quick click with one finger	Left mouse button		Click with one finger
Two-finger click	Right mouse button		Two-finger click
Quick double-tap with one finger	Double-tap with one finger		Quick double-tap with one finger
Quickly double-click and drag with one finger	Left click to select the target and drag		Quickly double-click and drag with one finger
Two fingers move vertically	Middle button vertical scroll		Two fingers move vertically
Two fingers move horizontally	Middle button horizontal scroll		Two fingers move horizontally

- 4 -

二、Touchpad Gestures

Gesture	Finger Schematic	Function Description
Enlarge		Enlarge goal,similar to holding down Ctrl key and scroll mouse wheel
Narrow		Narrow target,similar to holding down Ctrl key and scroll mouse wheel
Three-fingers click		Win+S key combination (open Cortana)
Four-fingers click		Win+A key combination (open Action + Center)
Three-fingers left draw		Alt + Shift + Tab key combination (active window switch)
Three-fingers right-zoned		Alt + Tab key combination (active window switch)
Three-fingers up plan		Win + Tab key combination (Open Task browser window)
Three-fingers draw down		Win + D key combination (show desktop)
From left edge to right plan		Win + Tab key combination (Open Task browser window)
From right to left draw edge		Win+A key combination (open Action + Center)
Draw down from top edge		Win+I key combination (narrow open window)
Draw upward from lower edge		Win+B key combination (show hide the taskbar)

- 5 -

① Attention

- 1.When not use for long time,suggest to close keyboard,in order to prolong battery lift
- 2.In order to get longer battery lift,charging before keyboard power light flashes,charging time must be better more than 2 hours

Energy saving sleep mode

When keyboard not use will be enter sleep mode after 15 minutes,work indicator will be off, press any key 5s to wake it up when need use again,then work indicator will turn on

Troubleshooting

- 1.Make sure the power is turned on
 - 2.Ensure keyboard operable distance
 - 3.Make sure the battery has power
 - 4.Ensure the device's Bluetooth was turned on
 - 5.Ensure the wireless keyboard was connected with the Bluetooth
 - 6.Ensure the wireless keyboard paired successfully
- After press power switch and it not working,charging the keyboard at first then reset it and turn on again

Cleaning

Washing,alcohol or a similar cleaning agent decontamination keyboard

Charging

When battery is low, the power indicator blinking,means need to charge the keyboard

- 1.Connect Genuine Parts USB cable B port to keyboard cradle
- 2.Connect USB cable A port to power adapter or computer USB port
- 3.When the keyboard is charging,the charging indicator will be on for a long time, and then it will turn on in green when it is fully charged

- 6 -

Warranty Card

User information

Company or personage full name _____

Contact address _____

TEL _____ Zip _____

The purchased product name and model NO. _____

Purchased date _____

This reason due to the product broken and damage is not include on the warranty:
(1) Accident,misuse,improper operation,or any unauthorized repair, modified or removed
(2) Improper operation or maintenance,when operation violation of the instructions or connection unsuitability power supply
(3) Or use consumables not provided by our company (such as spare batteries), unless applicable laws prohibited such restrictions



- 7 -

字体: 思源黑体中文 + arial字体英文