

说明书



型号：P300

欢迎：

欢迎购买此产品。使用前，请仔细阅读说明书。本产品是具有实时视频监控的实用类设备，适用深水区域探测、水下捕鱼。

特征：

1. 4.3英寸全彩液晶屏，可实时查看测试视频。
2. 分辨率高达1080P，电子图像稳定。
3. 直径毫米级防水摄像头，图像质量清晰，适用于水下捕鱼的工作环境。
4. 可调节LED灯，便于在黑暗环境中使用。
5. IP68防水。
6. 5000毫安电池容量，10~12小时超长续航时间。

应用：

水下15~30米实时观鱼，海底世界尽收眼底

按键名称：

1.电源开关

2.充电口/充电室接口

3.视频线接口

4.补光灯开关

5.喇叭

6.彩色黑白

7.缩放

功能介绍：

1.电源开关：ON开/ OFF关。
2.充电口/充电室接口：5V电源
3.视频线接口：视频输入
4.补光灯开关：ON开/ OFF关
5.喇叭：3扬声器调灯
6.彩色/黑白：彩色/黑白切换
7.缩放：3倍循环切换放大缩小

包装清单：

1.水下捕鱼器
2.用户指南
3.充电线
4.配件

技术参数：

型号	P300
显示屏	4.3英寸彩色液晶显示屏
摄像头分辨率	1920*1080
镜头视角	120°
续航	15m~30m 可选
重量	净重1m 重205.5m
防水	IP 68(只适用于镜头)

故障排除：

问题	解决方案
设备不能打开	1. 电池有电吗？ 2. 摄像头是否连接好了？
屏幕上有点迹或污染	用软布仔细清洗屏幕
充不进电	插入设备的直流输入端口，确保插座通电并且没有故障。

安全警告：

警告！ 阅读并理解所有说明。不遵守下列所有说明可能会导致触电、火灾和或严重的人身伤害。

AN100

AN101

P100

P150

P120 350°

P160

P40

P30

P50

P170

P210

Z40

P180

F280

P180

AN110

AN109

Z30

User Guidance



Model: P300

Welcome:

Thanks for choosing this product. Please read the instruction carefully before using the product. It is a practical equipment with real-time video viewing function and suitable for deep water detection and underwater fish detection.

Characteristics:

1. 4.3-inch Full-color LCD screen, you can view the test video in real time.
2. Resolution up to 1080P.
3. High sensitivity waterproof camera supplies clear images, suitable for working environment of underwater fish detection.
4. adjustable LED lights for easy use in dark environments.
5. IP68 Waterproof
6. 5000 milliamperes battery capacity with ultra long battery life up to 10-12 hours.

Scope of application

The device supports real-time watching 15-30 meters underwater, giving you a panoramic view of the underwater world

Button names:

1. Power switch
2. Charging port/power bank socket
3. Video cable socket
4. Fill light switch
5. Light adjustment
6. Color/black and white
7. Zoom

Function introduction:

1. Power switch: ON/OFF.
2. Charging port / power bank socket: 5V power supply
3. Video cable socket: video input
4. Fill light switch: ON / OFF
5. Light adjustment: 3 light levels for circular adjustment
6. Color/Black and White: switch between color/black and white
7. Zoom: 3 levels to switch between zooming in and out circularly

Packaging list:

1. Underwater fish detector
2. User guidance
3. Charging line
4. Accessories

Technical Parameters:

Model	P300
Display	4.3-inch Color LCD display
Camera resolution	1920*1080
Horizontal perspective	120°
Line length	15m-30m optional
Focal length	1m for clear water , 0.5m for muddy water
Waterproof	IP68 (only for lens)

Charging:

1. The product has a built-in 5000 mA lithium battery. When the battery is low, plug the small end of the power adapter into the left DC 5V-in port, and then plug the other end of the power adapter into a standard AC outlet to charge the battery. The red charging indicator on the panel remains on during charging and goes off when fully charged. Please unplug the power cord after fully charged.

Troubleshooting:

Problems	Solutions
Device cannot be turned on.	1. Dose the battery have power?
Blur or smudges on the screen	2. Is the power connected successfully? Carefully clean the screen with a soft cloth.

Safety Warning:

Warning! Please read and understand all instructions. Failure to follow the following instructions may result in electric shock, fire and/or serious personal injuries.

AN100

AN101

P100

P150

P120 350°

P160

P40

P30

P50

P170

P210

Z40

P180

F280

P180

AN110

AN109

Z30