

Please Check If The Following Items Are Available:

- | | |
|------------------------------------|-----------|
| 1. APPLLP 6 MAX Smart Watch | *1 |
| 2. Magnetic Charging Cable | *1 |
| 3. Watch Manual | *1 |
| 4. SIM card opener | *1 |

Please read the instruction manual carefully before use and keep it properly for quick and correct installation and use.

1. In Line With The Principle Of Continuous Improvement And Optimization, The Company Reserves The Right To Modify And Improve Any Product Information And Functions Described In The Document Without Prior Notice.

2. Due To The Continuous Improvement, Optimization And Upgrade Of The Product, The Actual Operation May Be Slightly Different From The Above, Please Refer To The Actual Operation.

3. The Product Pictures Shown In This Manual Are For illustration Only, Please Refer To The Actual Product. The Product Pictures In The Manual Are For Illustration Only, Please Refer To The Actual Product.

SIM Card Installation Instructions:

1. This device only supports Nano SIM cards. Before installing the SIM card, please check whether the network frequency

band used by the network operator is consistent with this product


2. APPLLP 6 MAX Support (2G / 3G / 4G Network); Frequency Bands Are: **GSM: 850 / 900 / 1800 / 1900 ; WCDMA: B1 / B2 / B5 / B8; LTE-FDD: B1 / B2 / B3 / B4 / B5 / B7 / B8 / B12 / B17 / B20 / B28 / B66; LTE-TDD: B34 / B38 / B39 / B40 / B41;**

Most Of The Current 2G Network Base Stations Have Gradually Been Closed. It Is Recommended To Use The Standard 4G Network Nano SIM Card. The SIM card Needs To Activate The Volte Function (For Activation Methods, Please Consult The Operator's Customer Service Or Business Office)


3. APPLLP 6 MAX Watch SIM Card Needs To Activate Data Traffic And Caller ID Functions

4. Do not use self-cutting cards and SIM cards from virtual operators. Using self-cutting cards may damage the watch or cause the card to not be read.

Please use a standard Nano card
(do not use card clipperg)



Ordinary
SIM Card



Micro SIM
Card



Nano SIM
Card

How To Charge And Malfunction Your Watch:

Before Using This Product, Please Charge The Watch For 2 Hours.If It Cannot Be Turned On, Please Charge The Device With a 5V/1A Or Higher Charger For More Than 20 Minutes To Activate The Battery.



①. Speaker; ②. Charging area; ③. Sensor

SIM Card Slot



Up Button:

Click on the dial page to enter the menu, Double click to switch the dial; Click on other pages to return, Long press to adjust the volume

Camera

Next button:

Long press to turn on/off,
Short press to turn on and off
the screen



Swipe Left:

Sports Data And
Heart Rate



Press And Hold The
Screen On The Main
Interface To Switch
The Watch Face



Slide Down:

Status Bar

Swipe Right:


Music Player

Strap Assembly

①. The short strap is directly above, and the long strap is directly below; ②. Align the strap interface with the groove of the watch body and insert it directly. You will hear a "click" sound to indicate that it is locked; ③. Check the firmness of the strap: gently pull the strap to confirm that it is not loose.



Strap Removal

- ①. Quick release button: There is a rectangular button on the inside of the connection between the strap and the watch body.
- ②. Press the button: Press the quick release button on one side and gently pull the strap to separate.



Slide down status bar function introduction

1. WIFI connection; 2. Traffic usage status; 3. Bluetooth; 4. Do Not Disturb mode; 5. Airplane mode; 6. Position switch; 7. Volume adjustment; 8. Screen brightness adjustment; 9. Screen ratio switching (when using the software, you can switch the screen to different ratios) ; 10. Screen recording function ;



How to connect the Bluetooth Assistant APP to a mobile phone

APLLP 6 MAX is compatible with Android 5.1 and iOS 8.2 and above. You can download HiSportPro and install it through the following QR code





Android: Search for HiSportPro in the Google Play app market to download


IOS: Search for HiSportPro in the App Store to download

1. Turn on the Bluetooth of your phone and watch; **2.** Turn on

the Bluetooth of your watch and enable detection; **3.** Open the Bluetooth Assistant and enable the Bluetooth service; **4.** Open HiSportPro on your phone, click Device-Bind Device, and scan the QR code on the watch to bind;




5. Download the APP on your phone and register and log in. After logging in, scan the QR code of the watch and follow the steps to bind. (Note: Click "Allow" or "Yes" on all pop-up windows)



AI function introduction:



Slide the status bar right: ChatGPT and DeepSeek



1. Swipe from left to right to enter the model selection page and click ChatGPT or DeepSeek;
2. The highlight effect indicates that the switch is successful ;
3. Click (57 languages) and (Chinese, English) respectively; you can view the mode and voice. **Currently only ChatGPT is**

supported for modification.

4. Use ChatGPT mode, DeekSeep mode



Select ChatGPT mode, press the back key or swipe left to return to the launcher homepage

After returning to the home page, long press the red circle area to perform voice input

12:50



April 22

Start Talking



Connecting..



GPT-4.1



ChatGPT

57 Languages

DeepSeek



Chinese, English

12:58



April 22

Select DeepSeek mode, press the back button or swipe left to return to the launcher home page. After returning to the home page, long press the green circle area to input voice



How to use AI iKKO APP

iKKO Connect is compatible with Android 8.1 and iOS 12 and

above. You can download and install iKKO Connect through the following QR code.



Android: Search for iKKO Connect in the Google Play app market to download

IOS: Search for iKKO Connect in the App Store to download

1. After downloading and installing, open iKKO Connect to create an account and log in;

Note: The password needs to be 8 digits.

2. Scan the member QR code on the watch with the mobile APP and bind and log in
3. After binding is completed, enter the home page
4. **Main functions:** ①. AI translation files, view AI translation records; ②. AI voice-to-text files, AI voice-to-text records, call recording records; ③. Chat records, you can use Chat and view Chat records on your mobile phone



ikko

Scan ActiveBuds Membership Code

Scan the QR code

How to Connect My ActiveBuds?



Swipe to the Home Screen.
Tap "Membership" at the bottom.
View your Membership QR code.

ikko

AI Translation
document



AI voice to text
document



Chat

Chat History





Simultaneous Interpretation

Translations 05/09/2025

Leur demandons de travailler autrement et parfois même renoncer à leur active.Historique....

We ask them to work differently and sometimes even give up their assets.Historical.It also sho...

memorandum

VT 04/28/2025

Call Notes 2025-04-28 20:59:37

Hello, hello, did you hear me?
That's it for now. I'm on speakerphone.
Bye.

VT 04/27/2025

Recording Notes 2025-04-27 11:12:29

Taylor series expansion of Euler's formula

1. Taylor series expansion of exponential function...

Chat

Shenzhen Airport

Chat

Shenzhen Airport, also known as Shenzhen Bao'an International Airport (IATA code: SZX), is a major aviation hub serving Shenzhen and surrounding areas. The airport is located in Bao'an District Shenzhen, about 32 kilometers from the city center. As one of China's important special economic zone airports, Shenzhen Airport connects major domestic cities and multiple international routes. It has modern terminals and facilities to provide passengers with a convenient and comfortable travel experience. The airport has convenient transportation, with subways, buses and taxis directly connected to the city. In recent years, Shenzhen Airport has continued to expand and upgrade to meet the growing passenger and cargo demand. The airport is located in Bao'an District, Shenzhen, about 32 kilometers from the city center.

消息



Common Troubleshooting Solutions:

The Phone Cannot Recognize The Sim Card?

- 1).** Install Another Sim Card To Rule Out The Possibility Of Damage.
- 2).** Check Whether The Sim Card Slot Is Dirty Or Deformed.

The Standby Time Is Short, Is There a Battery Problem?

The Standby Time Depends On The User's Usage Habits And Frequency. The Device Has Android System With Rich Features And Powerful Configuration. When Using Power-Hungry Applications Such As Social Media Applications And Games, Power Consumption Will Increase Accordingly.

Does The Watch Get Hot Easily?

Use High Power Applications For Extended Periods Of Time.

The Processor Generates a Lot Of Heat When Running At High Speeds, So The Surface Of The Watch Is Smaller And The Heat Dissipation Is Relatively Slow. Try To Avoid Using High-Power Applications For Extended Periods Of Time.

Does It Support Bluetooth Calling?

Not Supported, You Need To Install a Sim Card To Use It.

GPS Function Failure?

- 1).** Please Check Whether The GPS Is Turned On And Set The GPS To High-Precision Mode.
- 2).** When Using The GPS Function For The First Time, Please Use GPS Positioning In An Open Outdoor Area.

Kind Tips:

✖ The Test Results Of This Product Are For Reference Only And Are Not Intended For Any Medical Use Or Basis. Please Follow The Doctor's Instructions And Do Not Self-Diagnose Or Treat Based On The Treatment Results.

✖ The Watch Is Charged Magnetically. When Charging, Check That The Magnetic Contact Position Is Free Of Foreign Objects And Dirt. Due To The Loss Of The Battery Itself, Long-Term Inactivity May Cause The Product To Fail To Turn On Due To Battery Exhaustion. Users Are Asked To Charge Regularly Every Week To Ensure That The Device Is Normal. Work.

✖ Improper Operation May Cause The Product To Freeze. You Can Forcefully Restart The Watch By Pressing And Holding The Power Button For 10 Seconds.

✂ For Example, When Using The Mobile Network, Making Calls, Surfing The Internet, Video And Other High-Energy-Consuming Programs, The Power Consumption Will Be Relatively Large, And The Machine May Become Slightly Hot Or Hot, Which Is Normal. If The Machine Prompts a High Temperature Alarm, Please Reduce The Use Of Such High Power Consumption Applications.

✂ Water Resistance Is Not Permanent And May Weaken Over Time. Supports Hand Washing, Rain, And Short-Term Soaking. Scenarios Such As Hot Showers Are Not Supported.

✂ Note: Several Situations May Affect The Waterproofness: The Device Is Dropped, Bumped, Or Impacted; It Comes Into Contact With Soapy Water, Shower Gel, Detergent, Perfume,

Oil, Hot Water, Sauna And Other High-Temperature And High-Humidity Scenes.

✖ Equipment Damage Caused By Liquid Entering Is Not Covered By The Free Replacement Warranty.

✖ Our Company Reserves The Right To Modify The Contents Of This Manual Without Any Prior Notice. Some Functions Are Different In The Corresponding Software Versions, Which Is Normal.

Third Party Copyright Statement:

①. The Copyright Of The Licensed Content In This Product (Including But Not Limited To Text, Pictures, Audio, Video Or Software, Etc.) Belongs To The Copyright Owner, And The

Company Does Not Own The Intellectual Property Rights Of These Contents.

②. The Company Has Nothing To Do With The User's Own Copying, Installation, Downloading Of Third-Party Content (Including But Not Limited To Third-Party Works Such As Text, Pictures, Audio, Video Or Software) To This Product Or Attachments, As Well As The Uploading Of Third-Party Content Through This Product. Users Bear All Responsibilities And Risks Arising From Third-Party Content.

③. The Company Will Neither Provide Any Services To Users With Respect To The Above-Mentioned Third-Party Content, Nor Assume Any Responsibility For The Legality, Quality Or Other Aspects Of These Contents.