



EMERGENCY LIGHT

User Manual

Model: DH17



www.iyesido.com

Guangzhou Guan Su Ge Technology Co., Ltd.
Room A06, Floor 2, T28 Class, No. 16, East Of Hao Ke Zhou
Street, Shixi Village, HaiZhu District, Guangzhou, China.


Product Display

Thank You For Purchasing DH17 Product!
The Brief Description Of The Product Assures You
To Operate Freely, Fully Embodies The Value Of
This Product, Please Read Carefully Before Use.



Product Display

Product Diagram



Product Parameters


Model: DH17
Input: 5V~2A
USB Output: 5V~1A
LED Chip Model: 2835
Lumen: 2438LM (MAX)
Material: ABS+Tempered Glass
Battery Capacity: 10000 mAh
(2000mAh*5) 18650 Li-Ion Battery
Number Of LED Chips: 600PCS
(300 Cool White+300 Warm White)
Lighting Time:
About 9 Hours(High Brightness);
About 16 Hours(Normal Brightness)
Charging Time: About 7.5 Hours
Light Modes:
Full Brightness Neutral Light
(2400LM±50LM)
Cool White (1350LM±50LM);
Warm Light (1300LM±50LM)

Color Temperature:
Neutral Light (4500K±200K)
Cool White (7000K±200K)
Warm Light (3000K±200K)
Dimming Range: Continuous
Dimming From 10% To 100%
After Long Pressing For 3 Seconds
Tripod Screw Thread: 1/4 Nut
Power: 20W (MAX)
Battery Level Display:
25%~50%~75%~100%
Charging Interface: Type-C

The Above Data Is From The Laboratory; Actual Parameters May Vary Due
To The Product Or Other Factors.

List Of Package

1. Main Body 2. User Manual 3. Charging Cable



1



2



3

How To Use

1. Switch Settings:

Three Light Levels: Click To Switch Between Levels, Long Press For Continuous
Brightness Adjustment.
Level 1: Neutral Light, Level 2: Cool White, Level 3: Warm Light.

2. Dimming Method:

In Any Mode, Long Press The Switch For 3 Seconds To Set Brightness To 70%,
For 5 Seconds To Set It To 40%, And For 7 Seconds To Set It To 10%.

3. Battery Display:

①. The Four Green Lights Indicate Battery Levels Of 25%, 50%, 75%, And 100%.
When The Light Shows 25%, Please Note That The Battery Is Low And Recharge It
Promptly. The Device Will Automatically Power Off When The Battery Is Depleted.
②. During Charging, The Battery Indicator Lights Will Flash In Sequence From 25%
To 100%. When Fully Charged, All Four Lights Will Be Illuminated.
③. When Using The Usb Port To Charge A Phone, The Indicator Lights Display The
Actual Battery Level. If The Battery Is Too Low, It Will Not Charge The Phone, And
The Lights Will Not Turn On.

4. Mounting Methods:

The Plastic Handle Allows For Carrying, Can Be Used As A Desktop Support, And
The Strong Magnet On The Back Can Attach To Metal Surfaces (Note: Due To The
Weight Of The Lamp, It Should Be Placed Horizontally). The Plastic Handle With A
Hook Allows For Hanging, And The 1/4" Nut And Mounting Plate On The Lamp Body
Can Be Matched With A Bracket To Support 360° Adjustment.

5. Waterproof Instructions:

After Each Use, Please Ensure The Waterproof Silicone Plug Is Securely Closed.
The Lamp Is Splash-proof, But It Should Not Be Exposed To Heavy Rain Or
Submerged In Water.

6. Charging Instructions:

When Charging, Use The Charging Cable Provided By The Manufacturer,
Or Compatible Cables That Support 2a Or Higher Charging And Chargers
That Meet The 2a Requirement. Otherwise, If The Charging Cable Or
Charger Cannot Provide 2a, The Charging Time Will Be Extended Due To
The Large Battery Capacity In The Lamp.

Notes

- After Each Use, Please Make Sure The Waterproof Silicone Plug Is Securely Closed.
- To Ensure Optimal Performance, Fully Charge The Lamp Before Using It For The First Time.
- If The Lamp Is Not Used For An Extended Period, Please Charge It At Least Once A Month.
- During Charging, Both The Charger And The Lamp May Slightly Warm Up, Which Is Normal.
- Do Not Disassemble The Lamp Yourself To Prevent Damage Or Danger.
- Children Under 14 Should Use The Lamp Under Adult Supervision.

The Final Interpretation Of The Product Belongs
To Guan Su Ge Technology.