



LUGGAGE SCALE

User Manual

Model: MG41



www.iesido.com

Guangzhou Guan Su Ge Technology Co., Ltd.
Room A06,Floor 2,T28 Class,No.16,East Of Hao Ke Zhou
Street, Shixi Village, HaiZhu District,Guangzhou,China.


Product Display

Thank You For Purchasing MG41 Product!
The Brief Description Of The Product Assures You
To Operate Freely, Fully Embodies The Value Of
This Product, Please Read Carefully Before Use.



Product Display

Product Diagram




Product Parameters

Model: MG41 Max Weight Capacity: 50KG
Capacity: 50 kg / 110 lb / 1750 oz
Graduation: 50 g / 0.1 lb / 1 oz
Battery: 3V*1 Li-polymer (CR2032)
LCD Display Size: 33.8x12.8 mm

List Of Package

1. Mouse
2. User Manual



1

2

How To Use

Key Illustration

○/T/▲ : Switch On/switch Off/ Tare / Add Value

U/SET/▼ : Convert Weight Unit / Target Value Setting
Reduce Value/ Lock Function On/Off

The "H" Icon Will Only Appear When The Weight Exceeds 1kg, Indicating
That The Weight Value Is Locked; The "T" Icon Will Only Appear When The
Weight Exceeds 2kg.

Weighing

1. Strap The Webbing Belt Through The Luggage Handle And Secure The Hook
Of The Belt Onto The Triangle Ring.
2. Press **○/T/▲** To Switch On The Scale Before Lifting (Ensure There Is No Stress).
3. When The LCD Shows Zero, Lift The Scale Gently. Make Sure The Scale Is
Horizontal And Balanced. The Lcd Will Display The Weight Of The Luggage.
① After Locking, Pressing The **○/T/▲** Button Will Remove The Tare Weight.
When The Lcd Shows Zero And "T", It Indicates That The Tare Function Is
Active.
- ② The Weight Reading Will Be Locked After Flashing Three Times (When The
LCD Shows "H"). Press The **○/T/▲** Button To Reset The Lcd To Zero And
Enter Weighing Mode Again. The Scale Will Automatically Switch Off If Idle
For 2 Minutes.
4. Under Weighing Mode, Press **○/T/▲** Button 3 Seconds To Switch Off.
5. Press The **U/SET/▼** Button Five Times In Quick Succession To Enter The
Automatic Lock/non-lock Setting. "On" Indicates That The Automatic Locking
Function Is Enabled, And "Off" Indicates Continuous Weighing Without The
Locking Function. The Lock Function Is Enabled By Default Each Time The
Device Is Turned On.

How To Use

Target Value Setting


- In The Powered-on State, Long Press The **U/SET/▼** Button Until "S" Appears
To Enter The Target Value Setting. Indicated By The Symbol . Then, Press
The **○/T/▲** Button Or The **U/SET/▼** Button Briefly To Set The Target Value.
If Desired, Long Press The **U/SET/▼** Button Until "F" Appears To Save The
Setting.

- When The Setting Is Complete, The LCD Will Have A Red Backlight If The
Luggage Weight Exceeds The Target Value.

To Convert Weight Unit

When Switched On, Press **U/SET/▼** Button To Convert Weight Unit. Selected
Unit Works And Scale Will Enter Into Weight Mode.

Warning Indicators



1. Replace New Battery.
2. Scale Overload. Remove Item To Avoid
Damage. Max.weight Capacity Is Indicated
On The Scale.

To Replace The Battery:

Please Replace The Battery When The Lcd Shows "Lo". Open The Battery
Case Cover On The Back Of The Scale:

A. Take Out The Used Batteries (Using A Pointed Object If Needed).

B. Install The New Battery By Placing One Side Of The Battery First, Then
Pressing Down On The Other Side. Be Sure To Observe The Correct Polarity.

How To Use

Power

The Scale Is Powered By One 3V (CR2032) Lithium Battery. For First-time Use,
Open The Battery Case Cover And Remove The Battery Isolation Sheet.

Care And Maintenance

1. Wipe The Scale With A Slightly Damp Cloth. Do Not Immerse The Scale
In Water Or Use Chemical Or Abrasive Cleaning Agents.
2. Do Not Stress The Triangle Ring For Extended Periods. During Travel,
Keep The Scale Away From Objects With Sharp Ends (Such As Toys,
Stationery, Etc.) To Prevent The Scale From Being Switched On Frequently
And Draining The Battery.
3. To Ensure Accuracy, Do Not Use This Scale In A Strong Magnetic Field.
4. Keep The Scale Away From Babies And Children To Avoid The Risk Of
Swallowing The Batteries And Small Components.

The Final Interpretation Of The Product Belongs
To Guan Su Ge Technology.