



英文说明书-中性版-size 120*175mm

Product feature indication  1	Description of product features 1. Display Screen Displays the battery level and usage status prompts for the product. 2. Wireless charging output 10w power output, mobile phone wireless charging (requires mobile phone with wireless charging function) 3. Car emergency start-up It is used for problems such as car power loss, cold weather can not start and battery exhaustion, and can start family bridge vehicles, business SUVs, minivans, etc 4. USB Output Charge a variety of digital products, such as iPhones, tablets, GoPro, speakers, or other devices charged through a USB port. 5. TYPE-C Charging Input 5V/2.0A The wireless power supply is charged, and the charging port can be used to charge. 6. LED lights LED lights are divided into four levels: strong lighting, flashing, SOS, red and blue warning lights. 7. Key switch This power function enables the key. 2	Function operating instructions The car starts Simple four steps, easy to start, for your car to start smoothly make sure the battery is more than 75%. 1. Connect Attach the coppering connector to the power supply binding post. Make sure the battery is more than 75%. 2. Clamping Red clip to the positive pole of the car battery. Black clamp the negative pole of the car battery. 3. Start Enter the car to start the car and control the start time within 5 seconds. 4. Remove Remove the clip after booting, it is recommended to remove it within 30 seconds. Car start-up considerations 1. Confirm that the host power indicator light must be greater than 75% or more to start the car smoothly, and insert the blue plug of the battery clip into the car start port of the host. 2. Clip the red clip to the positive side of the battery and the black clip to the negative of the battery. 3. Try to start the car, each time the control starts within 5 seconds, remember not to screw the key and do not put it on for a long time to start, each time after starting needs to be more than 30 seconds apart, if the start 3 times can not start, please stop the start immediately, check whether the emergency power supply is sufficient to other problems in the car. 4. After the car starts, remove the starting power clip from the car battery within 30 seconds, otherwise the emergency starting power supply may be damaged. LED lighting LED lights are divided into four levels: strong lighting, flashing, SOS, red and blue warning lights. Press and hold to illuminate the light, click to flash, click to sos, and then press Stop or press to stop. Double-click the red and blue warning lights to turn on, and then double-click to turn them off. Wireless charging function (requires the phone to support wireless charging function) 1. Click the key switch to open the wireless charging output function 2. then put the power level 3. the wireless charging induction position on the back of the phone, aligned with the charging induction area of the power supply, you can charge. 3	Technical parameters+ fittings Product Model FJS700/800 Product Size 170x81x36 MM Wireless charging output 10W USB Output 5V/2.0A TYPE-C Charging Input 5V/2.0A The car starts 12V output Start-up Current See Fuseage Sticker for details Power capacity See Fuseage Sticker for details Fittings come standard Power host X1 User Manual X1 Start battery clip X1 Data cable X1 (red and black pair) Box X1 Note: Details are subject to physical delivery Precautions 1. During use or charging, if the device is slightly hot, it is normal, not a failure. 2. When using this product, keep the surrounding ventilation good, do not block the heat dissipation holes, and do not use in the following environments: 1) Wet places and places that are easily splashed by water. 2) Easy to drop place 3) Places where vibration, corrosion, dust, chemical gases are harmful 4) A place where flammable and explosive materials are stored 5) Place with high temperature heat source nearby 3. When not in use, remove all external devices to reduce power loss. 4. When not in use for a long time, it is recommended to keep the battery charged at a certain level and charge this product at least once every three months. 5. Do not scrub with coarse chemicals such as soap or other cleaning agents containing strong alkalis and strong acids. 6. Non-professionals please do not disassemble the machine, so as not to damage the machine and cause safety hazards. 7. Please do not throw or burn battery products that cannot be used, and please take care of the environment. 8. The power indicator on the product is for reference only, does not guarantee complete accuracy, if there is a slight error, it is a normal phenomenon. 9. All patterns used in this manual are for reference only, please refer to the actual product. 4																												
! 1. Please keep dry and away from fire. 2. Do not disassemble, puncture, or expose the port to do irregular operations or strong impact on the product. 3. For children or people with limited intelligence, attention should be paid to the use under the protection of the custodian. 5	Frequently Asked Questions Problem 1: After a few seconds of successful start-up, it automatically turns off or after removing the clip This situation is generally due to the excessive use of the car battery or serious aging caused, you can try to start again after running for 3 minutes to charge the battery, if this is still the case, it means that the battery has no power storage capacity, you must replace the new battery. Problem 2: Charging is not charged. 1. Check whether the display shows "IN", then "%" flashes, if neither is displayed, please check whether the charger connection is normal. 2. Please check whether the charging cable is correctly connected to the charger and whether there is power on the mains socket; You can try replacing a charger or charging cable and try again (this power supply You can use the phone's charger and cable directly). Problem 3: You can't charge your phone Check that the USB output of the boot power supply is turned on, and the power is at least one block or more than 10%. Check that the charging cable is properly connected or damaged, and if necessary, please replace the charging cable and try again Problem 4: Can't start the car The engine is completely in motion at start-up, first check whether the clips are reliably connected, if the battery cable head is dirty or badly rusted, please clean it up and try again. If it is determined that it has been connected, it is possible that the car has entered a protected state, and some models can try to press and hold the start button directly for about 10 seconds, waiting until the engine is moving. The engine moves at start-up, but it does not start; please check whether the clip is reliably connected to the copper head of the battery line, if the negative electrode is attached to the iron shell of the car, it will affect the starting performance. The above answer if not solve the problem. Please contact customer service to analyze and solve, do not disassemble the machine! Certificate Examine: _____ Date: _____ QC01 PASS 5	Warranty card This product provides customers with a warranty service of 12 months from the date of purchase Guarantee conditions: When you need warranty service, please present this warranty card and fill in the relevant content in detail. The Company provides Warranty Coverage: 1. Product quality problems occur in the normal state of use. 2. If the damage to the product is caused by the operation error, it is not covered by the warranty. 3. After disassembling the machine, no warranty will be granted. 4. Confirm that this tamper evident label is complete, if the word (VOID) appears, it means that it has been opened and no warranty will be granted. Products that are not covered by warranty, our company can provide maintenance services, and the maintenance costs need to be borne by the <table><tr><td>Product model</td><td></td><td>Factory number</td><td></td></tr><tr><td>Date of purchase</td><td></td><td>Repair date</td><td></td></tr><tr><td>Customer name</td><td></td><td>Contact number</td><td></td></tr><tr><td>Customer address</td><td colspan="3"></td></tr><tr><td>Sales units</td><td colspan="3"></td></tr><tr><td colspan="4">Description of product anomalies</td></tr><tr><td colspan="4"></td></tr></table> 6	Product model		Factory number		Date of purchase		Repair date		Customer name		Contact number		Customer address				Sales units				Description of product anomalies								12V MULTI-FUNCTION OUTDOOR ENERGY STORAGE POWER SUPPLY  Tips Please read this instruction manual carefully and follow the instructions for proper use of this product. 封面
Product model		Factory number																													
Date of purchase		Repair date																													
Customer name		Contact number																													
Customer address																															
Sales units																															
Description of product anomalies																															

封底

封面