V12 WIFI高清目镜摄像机使用说明书


2K(2304X1296P)

专利产品仿冒必究 专利号：2023120101464620

本产品是全光学WIFI目镜，与市场销售标准的单筒，双通，天文望远等传统的望远镜对接完美组合为二合一（WIFI目镜摄像机），可以将你看到远距离的视频与图像拍摄记录到数码摄像机里完整保存。

2K高清摄像机可以很好地实现远距离拍摄，应用领域：捕猎，钓鱼，观鸟，登山，户外探险冒险，音乐会等户外出行的最佳伴侣。

感谢你选择了我们的产品，请仔细观看用户手册，确保妥善安装和使用。



安装步骤：

1：拧开活动卡口　2：装上电子目镜　3：拧紧活动卡口　4：打开手机APP连接电子目镜　5：观看手机屏幕　6：手动调整望远镜焦距　7：开机按键　8：WIFI按键　9：LED灯　10：TF卡口　11：USB口

开关机按键使用：

长按开机按键3秒左右开机，开机（无卡）蓝灯长亮，（有卡）蓝灯闪表示录像。长按开机按键3秒左右灯灭关机。

WIFI打开关闭：

开机模式下，按住WIFI按键2秒左右，绿灯闪表示WIFI打开，可以与手机连接使用。长按WIFI按键2秒左右关闭WIFI绿灯灭。

充电：

没电状态插入USB/DC给本机充电，充电过程中红灯亮，充满红灯灭。

一、APP下载与安装：

官方APP下载 APP Store

扫码包装盒或者说明书的封面的二维码，安装完成后，点击录风者，进入录风者。

如图：

WIFI名称: ZHENYI-XXXX

密码：12345678

录风者

二、添加设备：

手机Mobile Phone：进入系统设置WIFI找到本机WIFI热点ZHENI-XXXX选择后，输入密码12345678进行WIFI点对点连接后，返回手机页面找到下载的（录风者）APP，点击进入APP，添加行车记录仪设备，完成添加后手机APP可以看到视频。

三、APP功能介绍：

1：记录仪：该页面对记录进行管理，可以添加本设备，查看，删除记录仪，并进入记录仪的视频预览界面。

2：相册，管理从记录仪下载到手机上面的图片和视频。

3：支持2K 2304X1296　1920X1080　2种高清视频格式转换。

4：更多的APP语言设置。

5：可一次支持2台手机同时观看。

6：支持上下翻转180度视频旋转。

连接电脑:

本机插入USB线连接电脑后，稍等几秒点按2次WIFI按键，自动连接电脑进入U盘模式。

四、WIFI记录仪功能介绍：

拍照：操作记录仪完成一次拍照，完成后该照片保存在记录仪上也可以通过手机端下载到手机保存。

缩放：进入视频全屏或是退出视频全屏。

1：记录仪文件：进入记录仪上的文件列表，进行录制分辨率，麦克风开关等设置。

2：记录仪文件下载：点击：记录仪文件，进入文件列表界面，点击，选择，按钮，选择中需要下载的图片或视频，点击：下载，开始下载文件，下载完成后，文件保存到手机上，可以通过相册进入查看 。

记录仪文件播放：

点击记录仪文件，进入文件列表界面，不用进行下载，可以直接播放记录仪上的视频，还可以对该视频的当前播放画面进行拍照。

下载：下载该视频到手机。

拍照：对当前播放的画面进行拍照并保存到手机。

五、相册：

进入相册可以对下载的手机上的图片或者视频进行管理，点击全部进入该类别的视频全部列表，文件列表按日期进行排列，点击选择可以多选文件进行操作。

视频：所有的视频文件

图片：所有的图片文件

紧急：碰撞感应的文件

六、视频播放：

对相册内的图片或者视频可以进行多种操作，如下图，对记录仪文件内的视频或是相册诶的视频进行播放时，可以选择倍速进行播放，以便快捷视频内容对关机视频进行慢速播放，比如1秒1帧或者10X倍速。

七、文件编辑：

选中相册中的文件，选中编辑，进入编辑界面，支持图片裁剪，滤镜美化，支持视频的裁剪，音乐添加等操作。

规格参数：

CMOS/SENSOR像素	400万
录像分辨率	2K/1080P
录像帧率	30帧1080/25帧 2K
照片分辨率	1920X1080/2304X1296
视频格式	MP4
镜头水平角度	5°
录像文件时间	1/3/5
WIFI点对点	支持
最大支持TF卡	128GB
电池（锂电池）	800毫安
录像时间（WIFI)打开	130分钟
语言	支持所有语言手机同步

V12 WIFI HD Mirror Camera User Manual

2K(2304X1296P)


Patented product. Unauthorized reproduction will be prosecuted.
Patent No: 2023120101464620

This product is a full optical WiFi eyepiece. It works perfectly with market standard monoculars, binoculars, and astronomical telescopes to become a two in one set (Wifi eyepiece camcorder). It can record the videos and pictures taken at far distances and store them in digital cameras.

This 2K high-definition camcorder can achieve long-distance photo shooting. Applications include: hunting, fishing, bird watching, mountain climbing, outdoor adventure and exploration and concert. Truly your best buddy!

Thank you for choosing our product. Please read the user manual carefully to ensure proper installation and use.





Installation procedures:

1.Unscrew the mounting groove
2.Install the electronic eyepiece
3.Tighten the mounting groove
4.Open the mobile phone APP to connect to the electronic eyepiece
5.View the mobile phone screen
6.Manually adjust the telescope focal length
7.Press the Start button
8.WiFi button
9.LED Light
10.TF card slot
11.USB Port

Use of ON/OFF buttons:

Long press the power button for about 3 seconds to turn on your eyepiece. When blue light is kept on(without card), or when blue light flashes (with card), it indicates video shooting is ready. Long press power button for about 3 seconds to shut off the eyepiece.

Open and Close WiFi:

After the eyepiece is powered on, press and hold the WiFi button for about 2 seconds. Once the green light flashes, it indicates that WiFi is opened and is ready for connecting to the mobile phone. Long press the WiFi button for about 2 seconds to close WiFi, the green light is off.

Charge the eyepiece:

In the state of no power, insert USB/DC to charge the eyepiece. Red light is on during charging. After charging is completed, the red light is off.

The eyepiece supports USB/DC or power bank charging while working.

I. APP Download and Installation:

Download at IOS/Android APP Store

Scan the QR code from the packaging box or the manual cover. After the installation is completed, click the QR code to find the 录风者, and open it,

as shown below.

WiFi name: ZHENYI-XXXX,

Password: 12345678

录风者

II. Add a Device:

Add a mobile phone: Go to phone system SETTING, find mobile phone hotspot Zheni-XXXX, tap it, enter password 12345678 to start point-to-point connection. After that, return to mobile and download 录风者APP, click to enter the APP, add driving recorder. After the recorder is added, you can watch videos.

III. Introduction to Functions:

1. Recorder: This page manages recording files. The recorder can be added, viewed or deleted. You can enter the video preview interface of the recorder.

2. Album: Pictures and videos downloaded from the recorder to your mobile phone can be managed here.

3. It supports two types of HD video format conversion, both 2K 2304X1296 and 1920x1080.

4. More APP language settings.

5. It supports watching on two mobile phones at the time.

6. It supports 180 degrees up and down video rotation.

Connecting to PC:

After inserting a USB cable into the computer, wait for a few seconds and press the WIFI button twice to automatically connect to the computer and enter USB mode.

IV. Introduction to Functions of WiFi Camera:

Taking photos: Operate the recorder and complete taking photos for one time. After the completion, photos are saved in the recorder. The photos can be downloaded to your mobile phone.

Zoom: Go to full screen of the video or exit full screen mode.

(1) Recorder file: Go to file list, set the recording resolution and microphone ON/OFF etc.

(2) Recorder file download: Tap recorder file, go to file list interface, tap Select button and select the pictures or videos you need to download, tap Download and start to download files. After downloading is finished, the file is saved on the mobile phone and you can view the files from Album.

Recorder file play

Tap the recorder file to enter the file list interface. Without downloading, you can directly play the video on the recorder. You can also take pictures of the current play screen while you are watching the video.

Download: Download the video to your phone.

Taking pictures: Take a picture of the currently played screen and save it to your mobile phone.

V. Album:

Go to Album to manage the pictures or videos that are downloaded on your mobile phone. Tap All to the list of all the videos under this menu. The file list is arranged by date. Click Select for multiple selections to operate.

Video: All video files

Picture: All picture files

Emergency: Collision induction files

VI. Play the Videos:

A variety of operations can be performed on the pictures or videos in the album. As per the picture shown below, when you play the videos or the video of the album in the recorder file, you can choose to play with faster speed so as to slow play shut off video with faster video content, for example, one second one frame or 10x speed.

VII. File Editing:

Select files in Album, select Edit, enter Edit interface, the system supports picture editing, filter beautification as well as video editing and adding music etc.

Specifications:

CMOS/SENSOR pixel	4M
Video resolution	2K/1080P
Video frame rate	30fps 1080/25 fps 2K
Photo resolution	1920x1080/2304/1296
Video format	MP4
Lens horizontal angle	5°
Video file time	1/3/5
WIFI point-to-point	Support
Maximum support TF card	128GB
Battery (Li-ion)	800mAh
Recording time (WiFi) open	130 minutes
Language	Support all language photo synchronization