

WiFi 6 Outdoor Mesh Router/AP/Repeater

www.wavlink.com/en_us/AERIAL_HD6

Scan the QR code or load the link for Quick Start Guide downloading

Hardware Overview

1 5G Antenna 2 2.4G Antenna 3 Grounding Terminal 4 Status LED 5 WAN/LAN Port (PoE) 6 Pair/Reset Button

Reset Button

Press and hold for 6 seconds to restore the device to default settings.

Pair Button

Press and hold for 1 second to pair with the existing EasyMesh Wi-Fi system.

Default Parameters

2.4G SSID: WAVLINK-AX_XXXX Default Login Password: admin
 5G SSID: WAVLINK-AX_5G_XXXX Official Website: www.wavlink.com
 Default IP: 192.168.10.1 Technical Support: support@wavlink.com
 Login: http://waplogin.link

Installation

1. Assembly

1. Pass the RJ45 cable through the waterproof connector cover.
 2. Screw the waterproof seal into the waterproof connector bracket.
 3. Pass the RJ45 cable through the waterproof connector bracket, and screw the waterproof connector bracket into the cover.
 4. Put the waterproof sealing ring on the waterproof connector bracket.
 5. Connect the RJ45 cable to WAN/LAN port.
 6. Screw the connecting cable into the 2.4G and 5G antenna connector and screw up the connector.

Note: Turn the wrench counterclockwise during assembly to tighten the bracket; Turn the wrench clockwise to loosen the bracket during disassembly.

2. Installation

2.1 Fix the device to the post with cable ties, or fix the device to the wall with screws, then follow the assembly step to install.

Note: If it is installed in an area where lightning occurs frequently, we recommend you to install the device via a ground connection to strengthen the lightning protection function.

2.2 Connection

2.2.1 Passive PoE (1) Wired(For Router/ AP Mode)

(2) Wireless(For Repeater/Mesh Agent Mode)

Configuration

1. Connecting to PC

1.1 Via Wireless

1.2 Active PoE (For AP/Router Mode)

Attention:
 1. Make sure you are using a certified CAT5e/CAT6 Ethernet cable with RJ45 connectors.
 2. Make sure the Ethernet cable length is less than 100 meters(328 feet).
 3. If it is fixed on the post, the length of the post must be less than the length of the cable ties.

2. Via Cable

1. Disconnect the Ethernet cable from your computer (if you have one).
 2. Turn on your WiFi, find the SSID of this product on your wireless devices (smartphone, tablet computer, laptop, et.) and place a connection.

For Windows users: [Screenshot of Windows network settings]
 For Mac users: [Screenshot of Mac network settings]

1. Connect the Ethernet cable to your PC/Laptop and the LAN DATA IN port of your PoE converter, then you can start the configuration of the device.
 If you are using the AP/Router function of this device, please connect the LAN DATA IN Port to the LAN port of the upper router after finishing 4.3 and 4.4.

2. When the router is connected to your devices at its first time, the login page will pop up, you also can enter 192.168.10.1 or waplogin.link into the address bar of browser of your PC/Laptop or phone. The default password is admin.

3. Select your Country/Region and Time Zone. For your network security, we suggest that you set a new login password, and click Next.

Note: The three colored bars in "Change Password" area indicates the strength of the login password.

正面

4. Mode Selection

This product has 4 modes.

4.1 Repeater Mode

For Repeater mode, we recommend you to choose "WISP", you can manually enter the WiFi SSID you need to connect or select the WiFi SSID in the list, and the Password needs to be the same as the WiFi password that this product has connected, then click on "Connect".

4.2 EasyMesh Agent Mode

If you have a router that supports EasyMesh function, then you can build a mesh system with this mode. Please configure according to the following steps:
 1. Log in to 192.168.10.1 or waplogin.link.
 2. In Mode Selection, please choose "EasyMesh Agent Mode".
 3. Click on the "Save" button.
 4. Enter the Pair Key of this device in the mesh network of the main router, or you can separately keep pressing the Pair button on the main router and sub-router for 1 second.

Note: If you are not sure how to start, please ask manufacturer for help.

4.3 AP Mode(LAN Bridge)

You can change the SSID or use the default one, as for the Encryption Mode, the default is WPA2-PSK, we recommend you to select WPA3/WPA2-MIX if your devices support. For your network security, please set a new password according to the rule. Then click on "Save" and wait for the setting process to complete.

4.4 Router Mode

If you choose the Router Mode, the system will guide you to select the WAN Type. As for the Encryption Mode, the default is WPA2-PSK, we recommend you to select WPA3/WPA2-MIX if your devices support. For your network security, we suggest you set a Password.

Which WAN Type am I supposed to choose?
 If you use DSL line and you are only provided an account name and a password by your ISP, choose PPPoE. If you use cable TV or fiber cable, choose DHCP(Dynamic IP). If you are provided information such as IP address, Subnet Mask and Default Gateway, choose Static IP.

Firmware Upgrade

If you need to update firmware, please proceed as the following steps:
Option I
 1. Download the latest firmware file on Wavlink website (www.wavlink.com->SUPPORT->Firmware).
 2. Extract the firmware from the downloaded file.
 3. Log in to waplogin.link or 192.168.10.1, then choose "Advanced" and select "Firmware Update".

Option II
 1. Log in to 192.168.10.1 or waplogin.link, then choose "Advanced" and select "Firmware Update".
 2. Click on "Check New Version" to find the latest version.
 3. Click on "Download and Upgrade", and wait for the firmware upgrade process to complete.
 Note: After updating firmware, please Reset The Device And Clear Your Browser Cache.

What is firmware upgrade and why do I need it?
 Firmware fixes bugs for your device, contains new features, and improves the experience of using the product. For your device update and security, please ask us for help, wrong upgrade may damage your device and void the product warranty.
 For more details, please visit our website www.wavlink.com and our technical support: support@wavlink.com.

More Mesh Devices

Generally, a mesh router device supports up to 7 (including the existing device). Therefore, if you need to add more mesh devices to build up a stable network in your home, you simply need to pair the new mesh devices with the existing network.

- Log in to waplogin.link or 192.168.10.1.
- "Advanced" -> "Mesh Network".
- You can add extra devices by entering their "Pair Key", and the sub-routers must be Mesh Agent Mode. You also can add extra devices by separately keeping pressing the Pair button for 1 second on the main router and sub-router after setting the sub-router as EasyMesh Agent Mode.

FAQ

Q1. Why doesn't the login page appear after entering http://waplogin.link?
 - If your computer is wirelessly connected, please verify that you have connected to the device's SSID. If your computer is connected via an Ethernet cable, please verify that the connection is stable.
 - Make sure your computer is set to obtain an IP address automatically.
 - Use the IP address to log in to the page. The default IP is 192.168.10.1. If the device is connected to the host Wi-Fi, please go to the router's DHCP client list to obtain the device's current IP address.
 - If the problem still exists, please reset the device again.

Q2. How do I restore the device to its factory default settings?
 - While the device is powered on, press and hold the Reset Button until all the LEDs turn on momentarily.

Q3. What should I do if the LED does not change to solid after completing?

- You may have entered the incorrect Wi-Fi password of your host Wi-Fi during the configuration. Please log into the device's web-based interface to check the password and try again.
 - Reset the device and go through the configuration again.

For more details, please refer to www.wavlink.com.

GNU General Public License Notice

This product includes software codes developed by third parties. These software codes are subject to either the GNU General Public License (GPL), Version 2, June 1991 or the GNU Lesser General Public License (LGPL), Version 2.1, February 1999. You can copy, distribute, and/or modify in accordance with the terms and conditions of GPL or LGPL.

The source code should be complete, if you want us to provide any additional source code files under GNU General Public License (GPL), please contact us in these matters. We are committed to meeting the requirements of the GNU General Public License (GPL). You are welcome to contact our local office to get the corresponding software and licenses. Please inform us of your contact details (full address) and the product code. We will send you a software package with the software and license for free.

The respective programs are distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Please refer to the GNU General Public License website for further information.
<http://www.gnu.org/licenses/old-licenses/gpl-2.0.html>
<http://www.gnu.org/licenses/lgpl.html>

WEEE Directive & Product Disposal
 At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

反面

名称: WN573HX1英语说明书WAVLINK-E1	
成品尺寸: 85x125 mm	展开尺寸: 680x125 mm
材质工艺: 105g铜版纸+四色印刷, 正反印, 风琴折	
制作时间: 2022.11.29	制图: 冯景祥
修改记录:	