

# IPC360Home Smart Camera

## Operating Instructions



IPC360home

Scan the QR code to download the "IPC360home"APP

Dear users, thank you for using our products. Before using, please read the operation manual carefully and save it for future reference

YCLSMS330

### 1.Register and log in

- 1.1 Open the APP "IPC360home"( Figure 1)
- 1.2 Click "No Account? Sign up" (Figure 2)
- 1.3 Enter the information as prompted and click "register" to complete it (Figure 3), and then log in the account to enter the main interface (Figure 4)




figure 1




figure 2




figure 3

### 2.Add camera

#### Method 1: Scan the QR code to add the camera

- 2.1 Click the plus symbol "+" on the upper right corner (Figure 4)
  - 2.2 Select the country and click "Next" (Figure 5)
  - 2.3 Scan the QR code on the camera (Figure 6)
- Note, if you can't find the QR code, or it's damaged, you can choose Method 2 to connect the camera




figure 4




figure 5




figure 6

- 2.4 After confirming that the camera indicator light flashes red quickly, click "Next" (Figure 7)
- 2.5 Click "Join" (Figure 8)
- 2.6 Choose your own WiFi, enter the correct WiFi password and click "OK" (Figure 9)




figure 7




figure 8




figure 9

- 2.7 Waiting device connecting (Figure 10)
- 2.8 After finishing adding, choose a name for your device and click "OK" (Figure 11)




figure 10




figure 11




figure 12

- 2.9 Add complete (Figure 12)
- ### Method 2: wireless hotspot connection (Cannot find the QR code)
- 3.1 Click the plus symbol "+" on the upper right corner (Figure 13)
  - 3.2 Select the country and click "Next" (Figure 14)
  - 3.3 Click "No QR Code Found" (Figure 15)




figure 13




figure 14




figure 15

- 3.4 Click on "WiFi camera" (Figure 16)
  - 3.5 After confirming that the camera indicator light flashes red quickly, click "Next" (Figure 17)
  - 3.6 Please refer to the video on the APP and connect to the wifi starting with IPC365 (Figure 18)
- (Android phones do not have this step, please refer to Figure 19)




figure 16




figure 17




figure 18

- 3.7 Click "Choose Device WiFi" (Figure 19)
- 3.8 Find the WiFi connection with the IPC365 name and click the return button on the upper left corner (Figure 20)
- 3.9 Choose your own WiFi, enter the correct WiFi password and click "OK" (Figure 21)




figure 19




figure 20




figure 21

- 3.10 Waiting device connecting (Figure 22)
- 3.11 After finishing adding, choose a name for your device and click "OK" (Figure 23)
- 3.12 Add complete (Figure 24)



figure 22




figure 23




figure 24

### Method 3: Wire mode (device with LAN port)

- 4.1 Click the plus symbol "+" on the upper right corner (Figure 25)
- 4.2 Select the country and click "Next" (Figure 26)
- 4.3 Click "The camera is connected to the router via a cable" (Figure 27)




figure 25




figure 26




figure 27

- 4.4 After searching the device ID number, click the device ID number (Figure 28)
- 4.5 After finishing adding, choose a name for your device and click "OK" (Figure 29)
- 4.6 Add complete (Figure 30)




figure 28




figure 29




figure 30

### Method 4: Watch without internet

- Note: This mode is for the mobile phone to connect to the camera hotspot to watch, not to remotely view and monitor
- 5.1 Click "Watch without Internet" on the login interface (Figure 31)
  - 5.2 Open the mobile phone system settings, connect to the WiFi interface, connect to the "IPC365-APXX" WiFi and return to the APP interface (Figure 32)
  - 5.3 Return to the APP and the connection is successful (Figure 33)




figure 31



figure 32




figure 33

### For more functions, please see Settings--Help

#### FAQ

- 1.Memory card not detected  
(Please make sure that the memory card can be used normally. Insert the correct direction)
2. The camera does not currently support 5G WiFi, if it is connected, please switch to 2.4G WiFi
3. Is the "wireless password error" prompt sounded during the camera connection?  
(Please check if the WiFi password entered is correct)
- 4.The camera is offline?  
(Please check whether the WiFi network is normal, check whether the power supply is normal)
- 5.How to change the network connection?  
(Press and hold the RESET button of the camera for 5 seconds until the camera beeps and the green light flashes quickly to reconnect)

## warranty card

your name:\_\_\_\_\_

shopping time:\_\_\_\_\_

contact details:\_\_\_\_\_

cause of issue:\_\_\_\_\_