

F180AT F102AT F109AT F360BT F180ATS F102ATS F109ATS F360BTS

中性中英文说明书
规格: 85X175MM
双面4色印刷, 风琴折

85.00 mm

INSTRUCTIONS

Apply to F180AT/F102AT/F109AT/F360BT
Note Kee

• Product introduction

1. keyboard body
2. keyboard
3. Touch edition
4. Protective cover
5. Charging keyboard interface
6. Wireless indicator
7. Manual
8. Type-c usb charging cable

• Load and unload the ipad

Classic: F180AT / F102AT / F360BT

Load ipad

- Put your iPad on the groove exactly
- Press your iPad let stuck in groove on the keyboard cover

Unload the ipad

- To unload the iPad by breaking out protective shell with your hands

Upgrade version: F109AT

- Turn the knobs on the bottom side of the iPad cover. Aim the iPad at the top cover groove and stick it in.
- And then you stick the bottom of the iPad in the groove. Turn the screw to hold the iPad in place.

Unload the ipad

- Turn the knobs on the bottom side of the iPad cover.
- By pulling the iPad out with both hands, you can remove iPad.

• Wireless connection

- Power on keyboard, press **⏻** keys, the keyboard will stay on searching state within 3 minutes.
- Tap your iPad's settings
- Settings > Bluetooth > iPad Keyboard
- Let your iPad Keep Wireless on

On other devices in the settings menu choose "iPad keyboard" wireless signal light go out, connection is successful.

Note: Bluetooth will automatically be connected when using next time.

• Product parameter

- Operating distance: 10 meters
- Working voltage: 3.3~4.2V
- Charging Current: 250 mA
- Standby Time: 60 days
- Continuous working time: <5 H(with backlight)
- Charging Time: <3 hours No backlight version 80 H
- Lithium battery capacity: Backlight version 500mAh
- Key life: >5 million strokes
- Operating temperature: 0 ~ 55°C

• Product Features

- Folio Smart 360 Rotate stand 7 Color Backlit Keyboard Case, which makes viewing more convenient and more versatile
- Flip Wireless keyboard with protective cover
- Fantastic, colorful breathing light and backlight. (Only breathing lamp version)
- Slim, comfortable keyboard

• Keyboard function introduction

- Home (Displays the iPad home screen)
- Darker
- Brighter
- Virtual keyboard
- Search (Launches the iPad search function)
- Back
- Play/pause
- Forward
- Mute
- Volume down
- Volume up
- Lock screen
- Bluetooth
- Closed/open
- Delete
- Tab
- Caps Lock

Special key instructions

- Alternate language input methods by pressing **Fn** + **⌘**.
- Fn** + **⏻** Turn on/off or adjust the backlight. Operating Method: Press once to turn on the backlight. Press again will increase the brightness. The third time will maximize the brightness. And the fourth time will turn off the backlight. (Only backlight version)
- Fn** + **⌘** To alternate the 7 backlit color (red, yellow, blue, green, cyan, purple, white) (Only backlight version)
- To type the character in grey area, hold shift and press the desired character.
- Other keys can realize some uncommon special characters
- Special short characters
Cut: **⌘** + **X** Paste: **⌘** + **V** Select all: **⌘** + **A** Copy: **⌘** + **C**
- Breathing lamp mode: There are 2 key combinations, **⌘** + **⏻** control breathing lamp switch, **⌘** + **⏻** controls the speed of the breathing lamp. (Only breathing lamp version)

• Charging instructions & maintenance

Indicators Instructions

- Blue LED: Blink at pairing. Stays on after paired successfully
- White LED: Caps lock indicator
- Red/Green LED: Blink at low-battery, the red light turns on when charging, green light when fully charged

★ To check power status, press the key and hold 1 second
Red LED flickers once: >25% power left
Red LED flickers twice: >50% power left
Red LED flickers 3 times: >75% power left

Maintenance: keep at normal temperature and charge at normal voltage. If you don't use it for long time, you need to charge your keyboard in time (once of two months).

• Keyboard battery disposal

Insert screwdriver between plastic top and metal case at keyboard top or bottom
Pry up plastic top and remove it completely. This action destroys keyboard
Turn top over and remove tape from battery.
Separate battery from circuit board
Dispose of battery according to local laws. Recycle remaining keyboard parts.

Table of Toxic and Hazardous Substance / Elements and Their Content							
Ingredients	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)	
Cable	X	O	O	O	O	O	
PWAs	X	O	O	O	O	O	
Plastic parts	O	O	O	O	O	O	
Membrane	O	O	O	O	O	O	
Meter parts	X	O	O	O	O	O	
Rubber dome	O	O	O	O	O	O	

O stands for this toxic and hazardous content in homogeneous material is under the SJ/T 11363-2006 Standards limits.
X stands for this toxic and hazardous content in homogeneous material is beyond the SJ/T 11363-2006 Standards limits.
Under the ingredients with "X" in the form all are up to RoHS.
on 27 January 2003 the European parliament and the council announce electronic equipment in limiting the use of certain hazardous substances directive 2002/95/EC.
Note: the environmental protection using period reference standard depends on the product of the regular work temperature and humidity conditions.
*We won't make you if changing the content of the instructions and specifications.
⚠ Caution: To use this product properly, please read the instructions.
MS&S-03-026

175.00 mm

使用手册

适用于 F180AT/F102AT/F109AT/F360BT

• 产品介绍

1. 键盘主体
2. 键盘
3. 触摸板
4. 保护壳
5. 键盘充电接口
6. 无线指示灯
7. 说明书
8. Type-c 数据充电线

• 操作使用方法

经典款: F180AT / F102AT / 360BT

装机

- 把您的iPad对准键盘盖下部凹槽
- 再将iPad卡入保护壳卡槽

卸机

- 固定键盘, 双手往外掰保护壳中间卡扣位置, 即可卸下

升级版: F109AT

- 旋转ipad盖底部两边旋钮, 将ipad对准上面凹槽处卡入
- 再将ipad底部卡入凹槽处, 旋转旋钮固定ipad

卸机

- 旋转ipad盖底部两边旋钮
- 双手往外掰ipad, 即可把机器卸下

• 无线连接

- 打开键盘电源, 然后按 **⏻** 键, 打开蓝牙配对模式, 键盘在三分钟内将处于等待搜索状态
- 打开您的iPad的设置
- Settings > Bluetooth > iPad Keyboard
- 让您的iPad保持在无线配对状态

在iPad的其他设备上搜索到键盘无线信号 "iPad Keyboard", 点击连接, 配对成功后, 无线信号指示灯将保持常亮状态

注: 第二次开始, 开机蓝牙自动连接

• 产品参数

- 操作距离: 10米
- 工作电压: 3.3~4.2V
- 充电电流: 250mA
- 待机时间: 60天
- 持续工作时间: <5小时(开启背光) 80小时(关闭背光)
- 充电时间: <3小时
- 锂电池容量: 500 mAh
- 工作温度: 0~55°C

• 产品特性

- 360度旋转: 可横向360度旋转, 纵向180度旋转, 让您的iPad在最佳视觉角度, 满足您的视觉需求
- 保护壳式保护键盘, 不伤机
- 带背光, 亮度可调节, 适合各种场合(仅背光灯款)
- 流畅的的键入体验, 舒适回弹的剪刀脚结构按键

• 键盘功能键介绍

- Home键(显示iPad的主屏幕)
- 更暗
- 更亮
- 显示/隐藏虚拟键盘
- 启动iPad搜索功能
- 上一首
- 播放/暂停
- 下一首
- 静音
- 减弱音量
- 增加音量
- 锁屏键
- 蓝牙
- 开关键
- 删除
- 切换下一步
- 大小写切换

部分功能按键特别说明

- 切换语言输入法, 需同时按 **Fn** + **⌘**
- Fn** + **⏻** 背光灯开启、关闭及亮度调节, 操作方式: 首次按为灯光开启, 第二次按为灯光亮度增强, 第三次按为灯光达到最亮, 第四次按为关闭灯光. (仅背光灯款)
- Fn** + **⌘** 背光颜色切换, 按这个键可以切换七种不同颜色(红、黄、蓝、绿、青、紫、白) (仅背光灯款)
- 你想输出灰色区域里的字, 请按住移动并按需字符
- 其他按键, 能打出一些不常用的特殊字符.
- 部分字符快捷键:
剪切: **⌘** + **X** 粘贴: **⌘** + **V** 全选: **⌘** + **A** 复制: **⌘** + **C**
- 呼吸灯模式: 有2个组合键, **⌘** + **⏻** 控制呼吸灯灭和亮, **⌘** + **⏻** 控制呼吸灯快和慢. (仅背光灯款)

• 充电和保养

指示灯特别说明

- 蓝灯: 无线配对状态时闪烁, 配对成功时蓝灯常亮
- 白灯: 大写时灯常亮, 小时时灯灭
- 红/绿灯: 低电闪烁, 充电时常亮红灯; 充满电时常亮绿灯.
- 开机状态下短按1秒开关键显示电量
红灯闪一下: 电量 > 25%
红灯闪两下: 电量 > 50%
红灯闪三下: 电量 > 75%

保养: 常温下保存, 正常电压下充电, 长时间不用, 需适时为键盘充电 (2个月左右充一次)

• 锂电池处理

将螺丝刀插入键盘顶部或底部的塑料外壳和金属壳之间
撬起塑料壳, 完全取出塑料壳. 这个操作会破坏键盘
把电池和电路板分开
用绝缘胶带粘住电池电线导电端, 防止短路
根据当地法律处理电池

有毒有害物质/元素及其含量表							
成分	铅	汞	六价铬	多溴联苯	多溴二苯醚		
电线	X	O	O	O	O	O	
PWAs	X	O	O	O	O	O	
塑料部分	O	O	O	O	O	O	
开关	O	O	O	O	O	O	
仪表部分	X	O	O	O	O	O	
硅胶	O	O	O	O	O	O	

O: 表示该有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006标准规定的限量要求以下。
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。
欧洲议会和理事会于2002年1月27日宣布电子设备限制某些有害物质的使用指令2002/95/EC。
注: 供参考的环境数据是在产品要求的正常使用和储存环境中测试获得, 比如湿度和温度等。
本说明书的内容及本产品的规格如变更, 恕不另行通知
⚠ 注意: 正确操作本产品, 请仔细阅读用户手册。
MS&S-03-026