



Repair electronics Expert

专业研发及生产液晶屏维修设备
Professional R&D and production of LCD screen repair equipment

Product description




Product parameters

Name	Heating separator	Numbering	988X
Temp range	0~120°C	Voltage	AC110/220V
Product Size	340*130*165mm	Package Size	385*150*200mm
Product Weight	3kg	Package weight	3.5kg

Notice: Due to the influence of measurement methods, processes, environment and other factors, the size and weight of the product may have slight errors from the marked values. Please refer to the actual product received. Thank you for your understanding and support!


Operating Instructions

01/ Main interface



02/ Operation steps

1. Press the bottom suction cup to make the product stick to the flat surface 6



2. Connect to power supply 8



(Before connecting to the power supply, please confirm whether it is 110V or 220V)

3. Control the platform by loosening (flipping and fixing 1) (rotating and fixing 3)



4. Temperature setting 10




Press (Set M) to enter the settings page, adjust the temperature value by +- press (Set M) again to confirm after adjustment

5. Press Vacuum Start 5 and place the screen on the work area to allow it to absorb 7





6. Take out the separation wire to separate the screen



7. After the split is completed, press Break Vacuum to complete the screen separation.



8. Remove OCA glue by adjusting the flip platform



Heating separation

Opposite separation, breaking the tradition

A good helper for electronic repair

1 使用须知

使用本产品前请仔细阅读本使用说明和安全须知，请妥善保管本使用说明。
为了保护您的权益，在您使用前，请确认以下资料的完备性：

- 1.988X主机
- 2.电源线
- 3.产品说明书

注意：产品丝印取决于实际购买的产品

2 使用安全

在使用本产品前后，请注意以下安全事项，以免造成人身或财产的损害：

- 请在指定的电压范围内使用本产品，避免过高或过低的电压，导致产品损坏或发生危险。
- 请勿将本产品放置在易燃或易爆的物品附近，避免引起火灾或爆炸。
- 请勿将本产品浸入水中或接触液体，避免造成电气故障或触电。
- 请勿将本产品拆开或改装，避免损坏产品或影响产品性能。
- 请勿将本产品用于非法或不合理的用途，避免造成不必要的麻烦或责任。
- 请在本产品使用时，遵守相关的法律法规，尊重他人的知识产权和隐私权。

3 故障排除

如果在本产品使用过程中遇到以下常见问题和故障，请参考以下解决方法和建议，或者联系我们的售后服务：

- 本产品无法通电或连接：请检查电源线、数据线是否插好，电源插座是否正常，电源开关是否打开，如果问题仍然存在，请联系我们的售后服务。
- 本产品输出数据不准确或异常：请检查输出线是否接触良好，输出设备是否正常工作，输出参数是否合理，如果问题仍然存在，请联系我们的售后服务。

产品示意图



产品参数

产品名称	加热分离机	产品型号	988X
温度范围	0~120°C	输入电压	AC110/220V
产品尺寸	340*130*165mm	包装尺寸	385*150*200mm
产品净重	3kg	包装重量	3.5kg

注意：由于测量方法、工艺、环境等因素的影响，产品的尺寸和重量可能与标注的数值有稍微的误差，请以收到的实际产品为准，感谢您的理解和支持！

操作说明

01/ 主界面



02/ 操作步骤

1.按下底部吸盘使产品与平面吸附 6



2.接入电源 8（接入电源前，请先确定是110V还是220V电压）



3.通过松开（翻转固定 1）(旋转固定 3)进行平台操控



4.温度设置 10




按下（设置M）进入设置页面，
通过+ -调节温度数值
调节完毕再次按下（设置M）确认

5.按下真空启动 5，并把屏幕放置工作区让其吸附 7




6.拿出分离钢丝进行分离屏幕



7.分割完成按下破真空，屏幕分离完成



8.通过调节翻转平台，进行OCA除胶



1 Usage notice

Please read these instructions for use and safety instructions carefully before using this product, and please keep these instructions for use properly. In order to protect your rights and interests, please confirm the completeness of the following information before you use it:

- 1. 988X product
- 2. Power cord
- 3. Product manual

Note: The product silk screen depends on the actual product purchased

2 Use safely

Before and after using this product, please pay attention to the following safety precautions to avoid personal or property damage:

- Please use this product within the specified voltage range to avoid excessively high or low voltage, which may cause product damage or danger.
- Do not place this product near flammable or explosive items to avoid causing fire or explosion.
- Do not immerse this product in water or contact with liquids to avoid electrical failure or electric shock.
- Do not disassemble or modify this product to avoid damaging the product or affecting product performance.
- Do not use this product for illegal or unreasonable purposes to avoid unnecessary trouble or liability.
- When using this product, please abide by relevant laws and regulations, and respect the intellectual property rights and privacy rights of others.

3 Trouble Shooting

If you encounter the following common problems and failures while using this product, please refer to the following solutions and suggestions, or contact our after-sales service:

- This product cannot be powered on or connected: Please check whether the power cord and data cable are plugged in properly, whether the power socket is normal, and whether the power switch is turned on. If the problem persists, please contact our after-sales service.
- The output data of this product is inaccurate or abnormal: Please check whether the output lines are in good contact, whether the output device is working normally, and whether the output parameters are reasonable. If the problem persists, please contact our after-sales service.