

尺寸：160x50mm 6折页(正反面)

正面

160mm

50mm

SMART GLASSES

INSTRUCTION MANUAL

使用指南

50mm

装箱清单

Smart Glass
x1

充电线
x1

清洁布
x1

说明书
x1

50mm

产品概括

1 充电接口

2 出音孔

3 触控区域

4 麦克风孔

5 摄影/拍照/通话/电源开关

6 摄像头

7 补光灯（提示灯）

50mm

快速入门

右侧按钮

开/关机
开机：长按3s
关机：长按5s

下载APP
手机扫描上方二维码
根据提示安装APP

连接手机
打开APP点击“连接设备”并
根据提示操作选择眼镜配对即可

充电
将Type-C线插入镜腿
并插上电源即可

50mm

多项功能

右侧按钮

视频/照片拍摄
单击按钮：拍照
双击按钮：录像
录像时，短按按钮一次结束

右侧按钮

语音通话
来电中，短按接听，长按2s挂断；
通话中，短按1次挂断

AI对话
眼镜链接手机APP后
语音呼唤“Hi Luma”即可

右侧按钮

录音
三击按钮：录音
录音时，短按一次结束

50mm

产品参数

产品名称：智能AI眼镜
视频分辨率：1080P 30帧/秒
单次录像最长时长：10分钟

Made in China

恢复出厂设置
长按右侧按钮10s
或者眼镜解除绑定后
自动恢复出厂设置

触控区域

音乐播放
音乐播放/暂停：单击触控区域
调节音量：前滑调大音量，后滑调小音量
切换下一首：双击触控区域
切换上一首：三击触控区域

反面

160mm

50mm

SMART GLASSES

INSTRUCTION MANUAL

50mm

Packing list

Smart Glasses
x1

Charging cable
x1

Cleaning cloth
x1

Instruction manual
X1

50mm

Product Overview

1 Charging Port

2 Speaker

3 Touch Area

4 Microphone

5 Photo / Video / Call / Power Button

6 Camera

7 Fill Light (Indicator Light)

50mm

Quick Start

Right Button

Power on/off
Power on: Long press for 3s
Power off: Long press for 5s

Download APP
Scan the QR code with your phone
and follow the instructions to
install the app

Connect to Phone
Open the app and tap "Connect
Device", then follow the instructions to
pair with the glasses

Charging
Insert the Type-C cable into the
temple of the glasses and connect
it to a power source.

50mm

Multiple Functions

Right Button

Video / Photo Capture
Single-click: Take photos
Double-click: Record videos
Short press once to stop recording
during video capture

Right Button

Voice call
Incoming call: Short press to answer
Long press 2s to reject
During call: Short press to hang up

Voice Assistant
Say "Hi Luma" after
connecting to the app

Right Button

Recording
Triple press: Start recording
Short press: Stop recording

50mm

PRODUCT PARAMETERS

Product Name: Smart AI Glasses
Video Resolution: 1080p 30fps
Maximum Single Recording Time: 10 minutes

Made in China

Restore
Long press the right button for 10s.
The device automatically resets to
factory settings after unpairing

Touch area

Music Playback
Play / Pause: Single tap the touch area
Volume Up: Swipe forward on the touch area
Volume Down: Swipe backward on the touch area
Next Track: Double tap the touch area
Previous Track: Triple tap the touch area