


SriHome®

Battery Camera Quick User Manual



Customer Service

Skype ID: tech.sricam

Website: www.sricam.com

E-Mail: support@sricam.com



SriHome202302-V2.0


Installing and charging the camera batteries

1. Insert two 18650 rechargeable batteries into the battery compartment .


Follow the steps shown below (you need to use a pair of batteries of the same brand and capacity, old and new batteries cannot be mixed)

2. When the battery power is exhausted, there is no need to take out the battery, you can directly use the power adapter to connect the camera to charge the battery, and the charging time is about 5-8 hours.



SH033B Battery Installation Procedure:



SH037B Battery Installation Procedure:



Products Introduction



Before starting setup

Make sure of the followings:

- This camera does not have AP hotspot mode, please connect to it via WiFi
- This camera does not support 5GHz WiFi, please connect via 2.4GHz WiFi
- Check that DHCP on the router is enabled.
- **For videos on how to set up our cameras, please visit: www.sricam.com/srihome/videos**

Step1. SriHome App Installation

Method 1: Search for "SriHome" on Google Play or iOS App Store.

Method 2: Scan the QR code to download "SriHome" App.




Android



iOS

Step2. Registration & Login on SriHome App

Step3. Connect the camera to the network



or


1. Turn on the camera

The camera will emit a continuous “beep” after 30 seconds.


Note: If there is no “beep” sound, keep holding the “RESET” button for 5 seconds until you hear a long “Beep”

2. Add the camera to the SriHome App


When you hear the continuous “beep”, follow the instructions of the SriHome App to add the device, as in the figure:




3-1




3-2




3-3



3-4



3-5



3-6

Introduction for monitoring interface:

- | | | | |
|-------------------|-------------------|---------------------|------------------------|
| 1. ☰ App Settings | 5. ⚙️ Settings | 9. 📷 Screenshots | 13. 🌙 Dimming |
| 2. 📄 Scan code | 6. 🖥️ Full screen | 10. 🔊 Speaker | 14. 🌙 Infrared mode |
| 3. 📱 Split Screen | 7. ⬆️ Up & down | 11. 🎤 Microphone | 15. 💡 Light mode |
| 4. ➕ Add | 8. 📺 Local record | 12. 💡 Light setting | 16. 🚨 Light alarm mode |

Trouble shooting:

- If you are unable to add a device on the app, please make sure the following:

- Before adding a device, you will hear continuous “beep”
(if there is no sound, RESET the device)
- Enter the correct Wi-Fi password. (It is recommended that wireless passwords do not use special characters such as !"£%)
- When you hear the “beep” sound, click “Next” in step 3-4.

FAQ: Share the camera with other users

To protect the user's privacy, the first user is an administrator by default. Others need administrator's permission to access the camera, or they cannot login even with ID and password. The way to get permission as follows:


Access the “SriHome” App, tap Settings -> Visitor Management -> Add.

There are 2 types of permissions:


Operator: Live video view, set time, alarm, record and network.

Visitor: Viewing video only in real time


Note: You can find the user's App ID in **App Settings**



FAQ-1



FAQ-2



FAQ-3